



KINNAIRD
BAGPIPES
& REEDS

www.kinnairdbagpipes.com

923 Emmeline Terr.
Saskatoon, SK. Canada S7J 5G7
306-249-2939
Fax: 306-249-2933

sales@kinnairdbagpipes.com

Replacing Rubber Tongue Clips on Kinnaird Carbon Fibre Drone Reeds

1. Remove old rubber tubing from reed by cutting with a knife.
2. Using a pair of needle nose pliers, insert the ends of the pliers inside the new rubber tubing.
3. Open up the tubing by spreading the jaws of the pliers.
4. Slip the tubing over the reed seat end of the reed, and remove the pliers.
5. Adjust the tubing, and ensure that the tongue is fully inserted underneath the tubing and is hitting the "stop" on the body of the reed under the tubing.